


Installation manual of VNX-C driver

STEP 1




Remove the five TORX10 screws holding the top cover. Remove the cover.

STEP 2



Disconnect the plugs from an electronic module.

STEP 3



Replace the electronic module for VNX-C and connect the plug to a socket marked with the red arrow. The module is ready for operation.

STEP 4

Assemble back the top cover (in reverse order as per described in step one).